

MHTC Series 1 Spare Parts




Table 2: Hydraulic Spare Parts

Item	Part Number	Description	Quantity
1	2544523	Hydraulic Bracket	1
2	2544521	Manifold Block, MH	1
3	1504297	Ftting Nipple Hex 0.5 NPT	6
4	2544516	Union Nut, 0.5" G Thread PVC	3
5	2544514	VALVE, SOLENOID 3/4 NPT, STAINLESS STEEL	3
6	1506288	Fitting Brass 0,75 BSP x 0,5 NPT	5
7	2529096	Flow Limiting Dev 0.75inx0.75in 0,6-8 l_min	4
8	2544510	Union Nut 0.75 G Thread	4
9	2544509	Hose Barb, For Swivel, 0.75in Hose, Poly	4
10	2544519	Vogel Pump 115V UL	1
11	1506285	Fill Valve Angled 12lpm Assy, 1506285 with threaded outlet 1/4 NPT	1
12	2544530	Splash Tube Clamp	1
13	2544527	Splash Tube - MH Fill Valve	1
14	2544524	Float, MH ReFlow	1
15	2544520	Fitting, Elbow, 0.5 in NPT Fem, polyprop	1
16*	2544532	Fitting, Elbow street 0.75in NPT, Poly	1
17*	2544929	Adapter .75 MNPT x .75 MGH	1
18	2544953	Conductivity sensor Kit	1
19	2544952	UV Light Kit	1
Not Shown	1501965	N/O Drain Valve	1
Not Shown	1504333	Low Pressure Switch	1
Not Shown	1321062	Flush Valve	1




Table 3: Control Box Spare Parts

Item	Part Number	Description	Quantity
1	2541251	PCB, Processor MH	1
2	2541226	PCB, Driver Board MH	1
3	2521279	PCB, Fault Remote Nortec	1
4	2532672	Transformer, 120/240-24 VAC 150VA	1
5	2522489	Switch Rocker DP/ST 10A-250V	1